



ExpressVote® Printer

Activation Card Printer

Check-in Integration

Works seamlessly with ES&S ExpressPoll®, ExpressLink® software and other pollbooks.

5 Pounds

Easy to store and transport.

Customizable

Header area can accommodate state-specific requirements.

Thermal Printing

No need to purchase ink cartridges or swap them out on Election Day.

Fast

Prints 11 to 19-inch activation cards in 5 seconds or less.



Little Printer, Big Savings

- Saves poll workers time because it's plug and play
- No need for special transportation or large storage space
- Eliminates ballot waste as it prints on demand
- Saves money — no ink or other consumables

Get It Right Every Time


- Be confident that the voter will receive the correct ballot. The ballot is printed on demand for each voter.
- Accelerates the voter check-in process with a secure, hardwired connection to the ExpressPoll electronic pollbook

A SEAMLESS EXPERIENCE FOR VOTERS AND POLL WORKERS

The ExpressVote Printer works with the ExpressPoll electronic pollbook and the Universal Voting System product family, including the ExpressVote® and ExpressVote® XL, to provide an end-to-end solution.

1

ExpressPoll finds the voter in the database and identifies the voter's correct ballot style.




2

It sends the information to the ExpressVote Printer.


3

The ExpressVote Printer prints the voter's ballot style onto the activation card.



4

The voter inserts the activation card into an ExpressVote or ExpressVote XL and the correct ballot is automatically displayed on screen.



or

